


Using the Equipment in F101-F308

1. **Turn on the projector** by pressing the power **on** key located in the top left of the remote controller.
2. To use a laptop, connect the VGA or HDMI cable.
 - a. **Windows computer:**
 - i. Press the **Windows key** and the **P** key simultaneously.
 - ii. Using your arrow keys, highlight **duplicate** and press enter.
 - b. **Apple computer:**
 - i. Click the **Apple** icon and select **System** Preferences
 - ii. Select **Displays**
 - iii. Select **Mirror** from the Arrangement menu.
3. To **adjust the volume**, press the volume buttons on the remote, check the volume controls on the computer or laptop.
4. To **blank the screen**, press the A/V mute button on the remote. To show the screen, press the button again.
5. **Turn off the projector** by pressing the **Off** button twice on the remote



For emergency support:
call 214-768-8888